
Installation Instruction

1. Put the inner split ring (6) on the inner handle (7), align the upper bar of the inner split ring with the square hole of the lock body and the screw holes on the two outer split rings, and fix it with self-tapping screws (8);

2. Put the outer split ring (4) on the outer handle (1), adjust the split ring into the square bar, adjust the feel, and tighten the center screw (3) with the Allen wrench (2).




No.	Name
1	Outer handle
2	Hex key
3	Center screw
4	Hand split circle
5	Lock body
6	Hand split circle
7	Inside handle
8	Self-tapping screw
9	Gusset plate
10	Snap box

Notice to Users:

1. Install the lock after the door and door frame have been painted and dried.
2. Do not paint and other corrosive products contact the surface of the products.
3. The user must be installed in accordance with the paper gauge of the corresponding product.
4. If not according to the requirements of the installation and use of the loss caused by the manufacturer does not assume any responsibility.


Single tongue lock body opening diagram



Instructions d'installation

1. Placez l'anneau fendu intérieur (6) sur la poignée intérieure (7), alignez la barre supérieure de l'anneau fendu intérieur avec le trou carré du corps de la serrure et les trous de vis sur les deux anneaux fendus extérieurs, puis fixez-le avec des vis autotaraudeuses (8).

2. Placez l'anneau fendu extérieur (4) sur la poignée extérieure (1), ajustez l'anneau fendu dans la barre carrée, ajustez la sensation, et serrez la vis centrale (3) avec la clé Allen (2).



Sans	Nom
1	poignée extérieure
2	clés hexagonales
3	Vis centrale
4	Cercle divisé à la main
5	Corps de serrure
6	Cercle divisé à la main
7	Poignée intérieure
8	Vis autotaraudeuse
9	Gusset plate
10	Boîte à pression

Avis aux utilisateurs :

1. Installez la serrure après que la porte et le cadre de la porte ont été peints et séchés.
2. Ne laissez pas la peinture et d'autres produits corrosifs entrer en contact avec la surface des produits.
3. L'utilisateur doit être installé conformément au gabarit de papier du produit correspondant.
4. Si l'installation n'est pas effectuée selon les exigences et que l'utilisation entraîne une perte, le fabricant n'assume aucune responsabilité.

Single tongue lock body opening diagram

